

Labs for the 21st Century
October 2002

Step-Variable Air Volume
Fume Hood Control
Case Study

Martin J. Wendel Jr. PE
Engineering Design Principal
Kling

Sarla Patel, PE
Senior Instrumentation & Controls Engineer
Kling


Design Challenge: Lab Fume Hood Control

- Fume Hoods
 - Critical Elements In Lab Design and Operation
 - Significant Impact On Lab Construction and Operating Costs
- Strategy
 - Constant Volume Vs. Variable Air Volume
- Cultural Issues

Constant Volume Fume Hoods

- Hood sashes are physically connected to “bypass dampers” that are reverse acting with position of sashes
- Provides **constant exhaust flow** through fume hood **regardless of sash position**
- CV fume hoods are **high energy users ... no reduction in exhaust** airflow as sashes are closed
- **No complex** instrumentation

Instrumentation for CV Hood




STEP-VARIABLE AIR VOLUME FUME HOOD CONTROL

Kling

Variable Air Volume Fume Hoods

- Controls **vary exhaust airflow** through hood based on **sash position**
- Airflow varied to **maintain constant face velocity** through open sash area
- VAV fume hoods provide energy saving opportunities via reduced airflows when sashes are closed
- Requires **complex instrumentation**

Instrumentation for VAV Hood



STEP-VARIABLE AIR VOLUME FUME HOOD CONTROL

Kling

CV vs. VAV INSTALLED COST COMPARISON

- Constant Volume Hood Control Installation

– Terminal Exhaust Box Controller	\$2,000
– Terminal Supply Box Controller	\$2,000
– Hood Alarm	\$1,000
– Unoccupied/occupied Override Switch	\$500
– Total	\$5,500

- Variable Air Volume Hood Control Installation

– Fume Hood Controller With Sash Sensor, Hood Alarm Panel and Exhaust Box Control	\$8,000
– Lab Control Panel With Flow Tracking, Supply Box and Room Temperature Control	\$7,000
– Total	\$15,000

Case Study

- 65,000 GSF Chemical Development Facility
- Approx. 75 fume hoods with four horizontal sashes
- 100 FPM face velocity through open sash area
- Typical 735 square foot lab module
 - Four 8 ft benchtop
 - Two 8 ft walk-in hoods
- Diversity Per module
 - Two (2) benchtop hoods at 50% open
 - Two (2) walk-in hoods at 50% open
 - Remaining hoods closed
- Scientists have bias against VAV
- Facility operations want to see energy savings
- Owner PM wants to see first cost savings

Design Challenge

Challenge:


- Provide System That Reconciles **Low First Cost** and **Low Operating Cost** With Cultural Bias Against VAV?

Solution:

- Step-Variable Air Volume Fume Hood Control

Step-Variable Volume Fume Hood Control

- Two-position constant volume box installed in exhaust duct serving the fume hood
- Each sash door furnished with door switch that “closes” when all sashes are shut
- Controls provided to index two-position exhaust box to its low setting when door switch contact closes, indicating that all sashes are closed
- Supply boxes serving the lab module programmed to “track” with position of exhaust boxes
- Lab/hood airflow and space temperature can be monitored and controlled by typical building management systems (BMS) – proprietary controls are not required



Sequence Of Operation – BMS Functions

- **Monitors** hood sash **positions** via sash **end switch**
- When sashes **open**, **indexes** exhaust box to **high** setpoint
- When sashes **close**, **indexes** exhaust box to **low** setpoint
- **Sums exhaust** from two-position CV exhaust boxes serving lab, then **adjusts supply** box to **track** with fume hood exhaust
- **Limits exhaust** per module based on **design diversity**
- Local **visual / audible alarm** in each lab ... when too many sashes are opened
- Maintains space **temperatures** by modulating **reheat coils** based on room thermostats and exhaust duct mounted temperature sensors (**cascade control**)

Step VAV Features and Benefits

- Step –VAV control provides the benefits of VAV at **less cost** with **less complex** instrumentation
- **Fast** control response time
- Control is **more “robust”** than traditional VAV
- Airflow control is provided by **time proven** BMS technology
- **Better match** to the “real world” usage of fume hoods

Summary

- Step-VAV **minimizes capital costs** when compared with traditional VAV
- Step VAV **reduces operating costs** by allowing setback of hoods whenever sashes are closed
- Fundamentally **simple two-position** control
- Controls used are proven technology
 - **Uncomplicated**
 - **Easy to maintain**
- Step –VAV control combines **best features of CV** and VAV controls while avoiding some perceived disadvantages

Labs for the 21st Century
October 2002

Step-Variable Air Volume
Fume Hood Control
Case Study

Martin J. Wendel Jr. PE
Engineering Design Principal
Kling

Sarla Patel, PE
Senior Instrumentation & Controls Engineer
Kling